


# Effect of nanoclay content and compatibilizer on viscoelastic properties of montmorillonite/polypropylene nanocomposites

**Surface morphology.** Dispersion of nanoclay in the composites with and without compatibilizer.  
*Viscoelastic behavior.*





Wide range of  
Temperature &  
Frequencies.

**Objective:** Atomic Force Microscopy (AFM): it is used to precise topographic images of a sample by scanning the surface with a nanometer-scale probe

*Minimal sample preparation, in air or liquid environment!*

**Instrumentation:** AFM used in the study is the INNOVA SPM, Bruker AXS Company.

*The scan conditions are chosen in order to obtain a stiffness contrast in which the brighter areas are stiffer than the darker areas. Thus, the nanoclay located on the surface appears brighter than the polypropylene matrix.*



**Fig. 9.** Height contrast AFM images of PPN<sub>9-UC</sub> showing uniform distribution of nanoclay in PP matrix.

**Fig. 10.** Height contrast AFM images of PPN<sub>9-C</sub> showing distribution of nanoclay in PP matrix.

10 mm x 10 mm x 3 mm injection molded nanocomposite specimens were used for analysis.

**Conclusion:** Nanoclay is not distributed uniformly and tends to be more aggregated in nanocomposites with compatibilizers. *This suggests that the addition of compatibilizer, m-TMlg-PP, is aiding to clustering of nanoclay instead of helping in uniform dispersion*

Reference: G.S. Venkatesh, Effect of nanoclay content and compatibilizer on viscoelastic properties of montmorillonite/polypropylene nanocomposites, (2012), 285-291, India.